

# Yealink VC Cloud Management Service Quick Start Guide-for Users


Applies to Version 2.5.0.0 or late

## Introduction

The users can read this guide to schedule conferences, join conferences, and control conferences.


# Logging into Yealink VC Cloud Management Service

- 1. Open a web browser.
- 2. Enter "https://yealinkvc.com/" in the address bar to go to the Login page of Yealink VC Cloud Management Service. Follow the steps in the picture below to log in.



## **Scheduling Conferences**

The participants can receive the conference invitation emails, they can also receive the conference notification on their VCS, VP59, SIP VP-T49G, Yealink VC Mobile&Desktop and so on.



## Joining Conferences

#### Do one of the following:

- Join conferences by logging into Yealink Cloud accounts on Yealink devices.
  - The supported devices are: VC880/VC800/VC500/VC400/VC200/VC120/VC110, VP59, SIP VP-T49G, and Yealink VC Mobile&Desktop.
- Join conferences via the web app of Yealink VC Cloud Management Service.


#### **VCS**

Take the VC800 videoconferencing system as an example, you can follow the steps below to join the confernece.


#### Logging into Yealink VC Cloud Management Service

1. On your remote control, navigate to **More->Setting->Advanced** (the default password is admin)->**Video Conference Platform**.

Follow the steps in the picture below to log in.




#### Joining the Conference from the Schedule




### VC Desktop & VC Mobile

Take the Yealink VC Desktop for Windows as an example, you can join the conference by the following steps.

Logging into Yealink VC Cloud Management Service



Joining the Conference from the Calendar




### SIP VP-T49G Phone

You can join the conference by the following steps.


#### Logging into Yealink VC Cloud Management Service


1. Click --> Advanced (the default password is admin)--> VC Account.
Follow the steps in the picture below to log in.



#### Joining the Conference from the Schedule








### Yealink VC Cloud Management Service Web App

- The supported browsers are: Google Chrome version 52 or later, Firefox version 52 or later, and 360 version 9.1 or later.
- 1. Open a web browser.
- 2. Enter "https://meeting.ylyun.com/meeting/join/#/login" in the address bar to visit the Home page of Yealink VC Cloud Management Service web app.


Follow the steps in the picture below to join the conference.



# **Controlling Video Conferences**


### **Controlling Conferences**

If you have the ongoing or upcoming conferences, you can follow the steps in the picture below to control the conferences.




### Controlling Education Mode Conferences

If you are the teacher in the education mode conference, you can control the conferences (You can subscribe to the education mode from Yealink). The details are described as below.




### Controlling Discussion/Training Mode Conferences

If you are the moderator in the discussion/training mode confernece, you can control the conferences. The details are described as below.



## **Enabling RTMP Live**

Click **Live** on the Conference Control page, and you can share the link with others, so they can watch the live broadcast of the conference.



## More Information

For more information about Yealink VC Cloud Management Service, visit https://yealinkvc.com/.